TEAK MAINTENANCE

Dear Readers,
Are you the owner of a yacht with Teak deck and furniture?
Do you already have Teak garden furniture at Your home?

Either way, you will be aware that You have several options for maintaining Teak, being the best natural material for outdoor.

So how to manage the maintenance of teak surfaces?
There are 4 basic paths:

1) The maintenance of your teak is managed by You and Your staff once a year or once every 2 years, using our maintenance products. Teak cleaner, Teak Protector, Teke Sealer.

2) Entrust the maintenance to an external company that restores the surfaces to a state similar to new. We reccomand to use our Teak Cleaner, Teak Sealer and Teak Protector.

3) Book our ARCO OUTDOOR CARE SERVICE carried out by our Team. You can write us by informing about n° pieces, type, age of furniture You would wish to be restored and ask for quotation at
contact@arcoarredi.com

4) For all people who appreciate the nice silversheen of weathered Teak, the maintainance becomes very easy by using once in a while our Teak Cleaner.

TEAK CLEANER

INSTRUCTIONS FOR USE:

1. Before using the TEAK PROTECTOR, eye protection and rubber gloves should be worn. Cover the ground under your working area before cleaning.
2. First moisten the furniture with water.
3. Shake TEAK CLEANER before use.
4. Apply TEAK CLEANER with a soft cloth or sponge. Allow to soak for 3 minutes.
5. Brush the furniture clean with a scrubbing pad in the direction of the grain.
6. Rinse furniture well with water.
7. For prolonged colour, leave the furniture to dry and treat with TEAK SEALER. For a silver grey colour, use TEAK PROTECTOR.

TEAK SEALER

Why is it so much better than teak-oil:

1. It maintains the light-brown colour of teak for a longer time:
   Up to 4 times longer than teak-oil • Up to twice as long as other sealers
2. It's environment-friendly because it is 100% water-based; no toxic fumes; non flammable; EcoSafe.
3. It is fast and easy to apply.
4. It's not an oil, it is not greasy: clothes stay clean.
5. It is resistant to mould and prevents black spots on the teak.

INSTRUCTIONS FOR USE:

1. Before using the TEAK PROTECTOR, eye protection and rubber gloves should be worn. Cover the ground under your work area before starting.
2. New teak: first clean with our Teak Cleaner to remove some of the natural teak oils (or weather for 2 weeks outside before treatment)
3. Grey teak or teak treated with teak-oil must first be cleaned with TEAK CLEANER.
4. If cleaned wood feels rough, sand lightly before treating with Protector. Make sure the teak is 100% dr and free of dust.
5. Shake and stir TEAK PROTECTOR at least a minute before use. Insufficient shaking can lead to uneven decolourisation.
6. We suggest you try the TEAK PROTECTOR on a small area first (e.g. the back of a leg) to judge if the colour meets your expectations.
7. Apply a very thin layer of TEAK PROTECTOR evenly over the furniture with a dust free cloth. Apply a second very thin coat after 30 minutes drying time
8. It is recommended that you treat your furniture with TEAK PROTECTOR at least once a vear.

TEAK PROTECTOR

An almost invisible shield to prevent food stains (coffee, ketchup, red wine, olive oil, etc.) from penetrating into teak.

INSTRUCTIONS FOR USE:

1. Before using the TEAK PROTECTOR, eye protection and rubber gloves should be worn. Cover the ground under your work area before starting.
2. New teak: first clean with our Teak Cleaner to remove some of the natural teak oils (or weather for 2 weeks outside before treatment).
3. Before using the TEAK PROTECTOR on dark grey teak, clean the wood with our teak cleaner. If cleaned wood feels rough, sand lightly before treating with TEAK PROTECTOR.
4. Make sure the teak is 100% dry and free of dust.
5. Shake for at least one minute before use. Apply a thin layer of TEAK PROTECTOR with a soft cloth.
6. Allow to dry for one hour and then apply a second thin coat of TEAK PROTECTOR. Let the teak dry for 48 hours before exposure to moisture.
7. It is recommended that vou treat vour teak furniture with TEAK PROTECTOR once a year. Tabletops should be treated more often.

TEAK CLEANER

Restores and brightens
wethered teak & hardwood

TEAK SEALER

Maintains the light-brown colour
of teak for a
longer time

TEAK PROTECTOR

Invisible after application.
Makes teak reppelent of water and
moisture.
Helps to prevent stains caused by
food and drinks.